

MOTORADER GRIP WARMERS

MotoRader Installation Instructions

Thankyou for choosing MotoRader Grip Warmers. These grip warmers are designed to heat your existitng grips for additional rider comfort.

Firstly you must remove your existitng grips, once removed clean the bars with prepsol or similar.

You can either use the included electrical tape or heat shrink tubing to now wrap around the bars as an insulation between the bars and the grip warmer pad.

Once the insulation has been applied peel the white backing paper off the grip warmers. The back of the grip warmers has a sticky backing which will allow you to now apply the warmers to the bars.

Once the grip warmers are in place you can now fit your existing grips back to the bars. You could either use hair spray or silicone spray or similar to make the job easier.

Find a suitable power source that is accessory not permanent power. Red wire is positive, blue is earth.

Your grip warmers have an OFF/HI/LOW switch and a variable temp control dial.

To make a neat installation you can use black cable ties to attach the wiring loom from the warmers to your handlebars etc.

You can now enjoy your winter rides in comfort!

